


# PACK BASIC

## User manual



Make sure all parts  
are in good condition for use.



# Pack Basic

## Step 1



1. Adjust the lateral ribbon as desired strength and attach both the left and right strap on the safety buckle.

## Step 2



2. Make sure everything is properly checked.

## Step 3



3. You can use the hip stool to let the baby sit comfortably on it.


# How to hold the baby

## Step 1



1. Posture for a newborn baby of 0-3 months.

## Step 2



2. Posture for the baby's neck to eliminate, a method for 3-6 months.

Name: DERYAN PACK Basic

Age: 0-36 months

Material: 100% cotton  
100% polyester

Model: PACK Basic

Load: <20kg

MADE IN CHINA

### Cleaning

- Wash the Pack with cold water, the product cannot go through the washing machine.
- Remove the cushion filler with wash to clean it.
- Use a mild detergent for washing of the hands. Clean separately, no expose to the sun and do not soak for a long time.



DERYAN Pack is suitable for babies from 0-24 months / 3.5 kg-15 kg.  
The age is a reference, it depends on the weight of the baby.

## **WARNING**

Read all instructions before assembling and using the Pack. Keep the instructions for future reference. Before each use, check that all buckles, snaps, straps and adjustments are secure. Before each use, check for torn seams, torn straps or fabric, and damaged fasteners. Ensure correct placement of the child in the product, including leg placement. Never use the Pack during activities such as cooking and cleaning where there is a heat source exposed to chemicals. Never wear the Pack while driving or as a passenger in a motor vehicle. The child should be able to face you until he or she can keep the head upright. Premature babies, infants with breathing difficulties and infants less than 4 months old are most at risk of choking. Never use the Pack if balance or mobility is impaired due to exercise, drowsiness or other medical conditions.

## **WARNING**

**HAZARD OF FALL** - Babies can fall through a wide leg opening or out of the push-chair.

- \* Adjust the leg openings to fit the baby's legs.
- \* Check that all parts are tight before each use.
- \* Be extra careful when leaning or walking.
- \* Never bend at the waist; bend at the knees.
- \* Only use the carrier for children between 10 kg and 18 kg.

**CHOKING HAZARD** - Babies under 4 months old can choke on this product if the face is pressed tight against the body.

- \* Do not tie the baby too tightly against your body.
- \* Leave room for head movement.
- \* Keep baby's face clear of obstructions at all times.

The child should face you until he or she can  
keep the head upright.